










# MOUNTING AND ANCHOR OPTIONS

	PART #	USE WITH MODEL #	WHEN	DESCRIPTION	DIMENSIONS	QTY PER SET
	6257	6203, 6205, 6401, 6403, 6407, 6804	Permanent Mounting in Fresh Concrete	Anchors must be purchased separately		1
	6258	6201, 6203, 6205, 6207, 6401, 6403	Permanent Mounting in Earth			1
	6259	2136, 2137, 2138, 2139, 2140, 2142, 6405, 6407, 6201, 6203, 6205, 6207, 6401, 6403	Permanent Mounting in Existing Concrete	Mushroom Head-zinc coated carbon steel anchor spike for mounting	3/8" x 6"	4
	6260	6803, 6806, 6809, 6903, 2103, 2106, 2109, 2113, 2203, 2206, 2213, 6811*, 2161*, 2163, 2165, 2167, 2169	Permanent Mounting in Existing Concrete	Mushroom Head-zinc coated carbon steel anchor spike for mounting	3/8" x 3"	8
	6265	2161*, 2451, 8040, 8140, 8013, 8113	Permanent Mounting in Existing Concrete	Mushroom Head-zinc coated carbon steel anchor spike for mounting	3/8" x 3"	4
	6266	2403, 2406, 2409, 2412, 2433, 2436, 2439, 2442	Permanent Mounting in Existing Concrete	Mushroom Head-zinc coated carbon steel anchor spike for mounting	3/8" x 4"	4
	6263	6803, 6806, 6809, 6903, 2103, 2106, 2109, 2113, 2203, 2206, 2213, 6811*, 2161*, 2163, 2165, 2167, 2169	Temporary Mounting in Existing Concrete	Lag bolts and shields	5/16" x 2"	16 (8 bolts, 8 shields)
	6264	2161*, 8040, 8140, 8013, 8113	Temporary Mounting in Existing Concrete	Lag bolts and shields	5/16" x 2"	8 (4 bolts, 4 shields)
	6267	2140, 2142	Mounting into Existing Asphalt	Galvanized 1/2" anchor for securing racks into asphalt	1/2" x 14"	4

Four anchors are recommended (at each corner). Mounting hardware is not included with purchase of rack.

\*6811 requires two anchor kits for mounting

\*2161 requires two kits:

Temporary: 6263 + 6264

Permanent: 6260 + 6265

Saris is proud to partner with these organizations:

